

Accelerated iSCSI Pack for HP Multifunction Gigabit Server Adapter



These activation instructions can also be found at www.hp.com/go/ice-license.

HP Accelerated iSCSI software is available at www.hp.com/go/iscsi or on the HP ProLiant Networking Software CD (version 8.40 or higher). For more information about this product, refer to the Accelerated iSCSI for HP Multifunction Network Adapters User Guide.

These instructions assume that the HP Network Configuration Utility (NCU) (release 8.40 or higher) is installed on an HP ProLiant system running Microsoft Windows 2003 (SP1 or above) or Microsoft Windows 2003 x64 (SP1 or above).

To install a single license key:

1. Double-click the NCU tray icon. The NCU Main window appears.
2. Click **License Manager**. The License Manager window appears.
3. Click **Install License(s)...** Select the **Install a single license key** option and enter the license key string.
4. Click **Install**. The installed license appears in the "Currently installed licenses" window.

To install multiple license keys from a key file:

1. Follow steps 1—3 above, selecting the **Install license keys** from a file option and click **Open License Key File....** The Open dialog box appears.
2. Select the [filename].key file and click **Open**. A list of keys available for installation displays in the "Install ProLiant Essentials License Key(s)" window.
3. Select the license keys to install by clicking the check boxes. Selecting **Invert all** reverses all check box selections.
4. Click **Install** to install all selected licenses.

After installing the license key, use the HP NCU to enable the Accelerated iSCSI feature. Retain the license key for future reference. The key is needed for technical support and future upgrades.

Count on HP for software support solutions

One and three year 24x7 Technical Support Care Packs are available for this product. For more information about this service, see www.hp.com/services/swtechsupport.

To purchase Care Packs, or for technical issues using Integrated Lights-Out products purchased through HP, contact an HP support center: http://welcome.hp.com/country/us/en/wwwcontact_us.html.

これらのアクティベーション手順は、HPのWebサイト<http://www.hp.com/jp/ice-license>にも記載されています。

HP Accelerated iSCSIソフトウェアは、HPのWebサイト<http://www.hp.com/jp/iscsi>またはHP ProLiant Networking Software CD (バージョン8.40以降) から入手できます。この製品について詳しくは、『HP Accelerated iSCSIユーザ ガイド マルチファンクション ネットワーク アダプタ用』を参照してください。

これらの手順は、Microsoft Windows 2003 (SP1以上) またはMicrosoft Windows 2003 x64 (SP1以上) を搭載するHP ProLiantシステムに、HP ネットワーク コンフィギュレーション ユーティリティ (NCU) (リリース8.40以降) がインストールされていることを前提としています。

1つのライセンス キーをインストールするには、以下の手順に従ってください。

1. NCUトレイ アイコンをダブルクリックします。NCUメイン ウィンドウが表示されます。
2. [ライセンス]をクリックします。ライセンス マネージャ ウィンドウが表示されます。
3. [インストール ライセンス]をクリックします。[単一ライセンス キーのインストール]オプションを選択し、ライセンス キーを入力します。
4. [インストール]をクリックします。インストールされたライセンスが[現在のインストール済みのライセンス]ウィンドウに表示されます。

キー ファイルから複数のライセンス キーをインストールするには、以下の手順に従ってください。

1. 上記の手順1から3を実行して、[ファイルからライセンス キーのインストール]オプションを選択し、[ライセンス キー ファイルを開く]をクリックします。[開く]ダイアログ ボックスが表示されます。
2. [ファイル名].keyファイルを選択し、[開く]をクリックします。[ProLiant Essentialsライセンス キーのインストール]ウィンドウに利用可能なキーのリストが表示されます。
3. チェック ボックスをクリックしてインストールするライセンス キーを選択します。[選択/解除の反転]を選択するとチェック ボックスの選択を逆にします。
4. [インストール]をクリックして、選択されたライセンスをインストールします。

ライセンス キーをインストールしたら、HP NCUを使用してAccelerated iSCSI機能を有効にします。後で参照するためにライセンス キーを記録します。テクニカル サポートや将来のアップグレードには、キーが必要となります。

信頼性の高いHPのソフトウェア サポート ソリューション

この製品には、1年間および3年間の24時間年中無休のテクニカル サポートCare Packが用意されています。このサービスについて詳しくは、HPのWebサイト<http://h50146.www5.hp.com/services/ps/carepack/fixd/software.html>を参照してください。

Care Packの購入について、またHPから購入したIntegrated Lights-Out製品の使用に関する技術的な問題については、HPのWebサイトhttp://welcome.hp.com/country/jp/ja/contact_us.htmlから、HPのサポート センタにお問い合わせください。

© 2007, 2008 Hewlett Packard Development Company L.P.

Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation

Second Edition (July 2008)
Part Number 461018-022