

HP Integrated Lights-Out Advanced Pack



These activation instructions can also be found at www.hp.com/go/ice-license.

Your HP Integrated Lights-Out (iLO) Advanced Pack license key might contain one or more licenses. One license is required for each managed target system.

These instructions assume the network client has a network connection to the iLO or iLO 2 management processor.

To install the iLO Advanced Pack license and enable the iLO Advanced Pack functionality using a supported web browser:

1. Log in to iLO or iLO 2 with a user ID that has the Configure iLO Settings privilege.
2. Click the **Administration** tab.
3. Click **Licensing** to display the iLO or iLO 2 Licensing page.
4. Enter the 5 x 5-character license key in the space provided.
5. Click **Licensing** to clear the fields and reload the page.
6. Click **Install**. The End User License Agreement (EULA) confirmation displays. The EULA details are available on the HP website at www.hp.com/servers/lights-out and with the license kit.
7. Click **OK** to accept the terms of the EULA enclosed with this product. The features of the iLO Advanced Pack are now enabled.

HP recommends you retain the license key for future reference. The license key is required for technical support and future upgrades.

For activation of iLO Advanced Pack functionality on groups of iLO or iLO 2 processors, use the HP Lights-Out Configuration Utility. Details on this scripting utility and activation using the command line interface are located in the *HP Integrated Lights-Out Management Processor Scripting and Command Line Resource Guide* on the HP website at www.hp.com/bizsupport. Select **Manuals**, and search for iLO or iLO 2.

This software includes one year of 24 x 7 Software Technical Support and Update Service. Registration for this service will automatically take place upon redemption of the license certificate/key online. For more information about this service, see www.hp.com/services/insight.

これらのアクティベーション手順は、HPのWebサイト<http://www.hp.com/jp/ice-license>にも記載されています。

HP Integrated Lights-Out (iLO) Advanced Packライセンス キーには、複数のライセンスが含まれる場合があります。管理対象システム1台当たり、1つのライセンスが必要です。

これらの手順は、ネットワーク クライアントがiLOまたはiLO 2 マネジメント プロセッサにネットワーク接続できることを前提としています。

サポートされているWebブラウザを使用して、iLO Advanced Packライセンスをインストールし、iLO Advanced Pack機能を有効にするには、以下の手順に従ってください。

1. iLOの設定権限を持っているユーザIDを使用して、iLOまたはiLO 2にログインします。
2. [管理]タブをクリックします。
3. [ライセンシング]をクリックして、iLOまたはiLO 2の[ライセンシング]ページを表示します。
4. 5×5文字のライセンス キーを、スペースに入力します。
5. [ライセンシング]をクリックして、フィールドをクリアし、ページを再ロードします。
6. [インストール]をクリックします。エンド ユーザ使用許諾契約書 (EULA) の確認画面が表示されます。EULAの内容の詳細は、HPのWebサイト<http://www.hp.com/servers/lights-out> (英語) およびライセンス キットから入手できます。
7. この製品に付属のEULAの内容に同意する場合は、[OK]をクリックします。これで、iLO Advanced Packの機能が有効になります。

将来使用するために、ライセンス キーを保存しておくことをおすすめします。テクニカル サポートや将来のアップグレードには、ライセンス キーが必要となります。

iLOまたはiLO 2プロセッサのグループでiLO Advanced Packの機能を有効にするには、HP Lights-Out設定ユーティリティを使用します。このスクリプティング ユーティリティおよびコマンド ライン インタフェースを使用したアクティベーションについては、HPのWebサイト<http://www.hp.com/jp/manual>にある『HP Integrated Lights-Outマネジメント プロセッサスクリプティング/コマンド ライン リソース ガイド』を参照してください。

このソフトウェアには、ソフトウェア テクニカル サポートおよびソフトウェア アップデートが含まれています。このサービスについては詳しくは、<http://www.hp.com/services/insight> (英語) を参照してください。